


CAMERA STAND INSTALLATION GUIDE




Screw




Nut A (Locking Nut)




Nut B (Center Nut)




Camera Mount Adapter



Base Plate



Gooseneck Arm



Single Pole




Telescopic Pole


Contains an inner extension pole for adjustable height




Adjustment Part




1. Insert the power cable through the wire hole of the single pole and pull it through the connector port.




2. Gently push the extension pole out from one end of the telescopic pole by approximately 10 cm.




3. Insert the power cable into the telescopic pole connector and pull it through the wire hole in the extension pole.



4. Connect the single pole to the telescopic pole and then attach the end of the single pole to the base plate.




5. Fully extend the telescopic pole and then slide the adjustment part onto the telescopic pole and tighten it for secure use.




6. Connect the gooseneck arm to the telescopic pole.


Check the diagram to identify your camera's base before mounting the adapter.




For two-screw models (BBM002, BBM003, SBM001-009), install the adapter directly.




For single-screw models (BBM001, BBM010), remove one screw from the adapter before installation.




7. Secure Nut B into the center of the adapter.




8. Connect the gooseneck arm to the camera mounting adapter.



9. Insert one screw from the camera mounting adapter into the mounting hole on the bottom of the camera.



10. Insert the second screw into the remaining hole; then tighten both Nuts A to hold everything securely in place. (If it is a single-screw model, skip this step.)



11. The completed installation is shown in the image above.

Looking for help?

Contact us to get expert support.

www.thedrcare.com

support@thedrcare.com