




BRACKET INSTALLATION GUIDE



Screw A




Screw B




Wall Anchor




Nut




1. Adjust the bracket to the desired angle and then tighten it.




2. Place the wall mount bracket at the selected spot and mark the screw holes with a pencil.




3. Drill holes in the wall (6.0 mm diameter) and insert the wall anchors.




4. Insert one Screw B from the bracket into the mounting hole on the bottom of the camera.



5. Insert the other Screw B into the remaining screw hole on the bottom of the camera, and tighten both nuts securely. Skip this step for cameras with a single screw hole mount.



6. Insert the screws through the brackets mounting holes and tighten them into the anchors to secure the bracket. (Ensure that the end intended for camera installation is facing upward.)



7. Once installed, adjust the camera's angle (up, down, left, right) via the monitor control panel to achieve the desired viewing angle.